

PS-308

Passive / Non-Powered Coaxial Speaker



KTV/PORTABLE SERIES PRO-Line Coaxial Driver

Specifications

Type	Center Monitor
Max. Power Handling	300 Watts
Cabinet Type	Plastic
Supported Fixture	Ground, Wall Mount, Floor Stand
Woofer	8 inches (1 unit)
Tweeter	2-Way Full Range, HF Horn
Frequency Response	65 Hz ~ 15 kHz
Sensitivity	90 dB
Crossover Frequency	2.6 kHz
Highlighted Features	2-Way Full Range Plastic Speaker with Coaxial Horn
Dimension (WxHxD)	12.7x15.6x10.7 inches / 32.3x39.7x27.1 cm
Packing Dimension (WxHxD)	14.7x17.8x12.6 inches / 37.4x45.3x32.1 cm
Net Weight	14.3 Lbs / 6.5 kg (each)
Shipping Weight	17.6 Lbs / 8 kg (each)

High Portability and Convenience



How to use the Portable Series speakers

Better Music Builder create more product lines for consumer use. Portable Series speakers have 3 different woofer driver sizes: the 8" 10" and 12", and our models are: PS-308, PS-308A, PS-310, PS-310A, PS-312, and PS-312A. You need a pair of Portable Speakers system for it to work – one active (built-in powered) and the other passive (non-powered). So you don't have to carry the powered amplifier and other components.

The active unit speaker (built-in powered) is powered to drive the second non-powered speaker unit. The active unit speaker has two microphone inputs and music source input (such as iPhone or MP3) in the front panel. But you have to get the right cable to hook-up from the music source to the active unit speaker. The active unit speaker uses the 1/4" input jack.

Since the music and microphone volume and music tone buttons are in the front panel of the active unit speaker (built-in powered), you can make easy adjustments. What you need is a speakon (NL4) cable to connect the active unit to the passive unit speaker(s), but the cable must be purchase separately.

When you have decided on the length of the cable, you may contact our authorized dealers or you may go to our website www.bettermusicbuilder.com.

